

Fix-it Foot & High Bloc

The neat and tidy rubber Fix-it Foot is simple, durable and comes in a variety of sizes. Extra clearance can be created using a High Bloc which fits underneath.



Key Features

- Quick and simple install.
- Aluminium channel securely anchored in top for easy fixing of services.
- Wide range of height and length options available.
- Durable recycled rubber reduces vibration and adds stability.

Kit Includes	
Rubber Foot	× 2
Bag with screws	× 2



Description	Product Code	Length (mm)	Width (mm)	Height (mm)	Weight (Kg)	Max. Load (Kg)	Pair with screw set
250	B6735	250	180	95	2.4	82	and the second se
250 – Rubber pair with screw set	B0084						
400	B6736	400	180	95	3.5	128	Contraction of the second
400 – Rubber pair with screw set	B0085						
600	B6737	600	180	95	5.8	224	HING HOLD SAL
600 – Rubber pair with screw set	B0386						
1000	B9096	1000	180	95	9.9	295	
1000 – Rubber pair with screw set	B0134						
250 Low	B9043	250	130	50	1.3	82	
400 Low	B9045	400	130	50	2.1	128	Sector Sector Contractions of the
400 Low – Rubber pair with screw set	B0136						
500 Low	B9368	500	130	50	2.5	134	Automatical Law
500 Low – Rubber pair with screw set	B0216						
600 High Bloc	B6974	600	180	120	10.2	224	
1000 High Bloc	B6973	1000	180	120	17.7	295	

Information correct at time of going to press. Not all products are available in all regions.